

litech

EasyMate 2



Quick Set-Up Guide V2
Model number: OLT2914V2

Contents

SIM insertion	3
Powering on/off	3
Lock/unlock keypad	4
Save contacts to phonebook	5
Photo/speed dial	6
Ringtone	7
Volume key status	8
Auto answer when removed from charger ...	9
Loudspeaker	9
Voice guidance	10
Amplify receiver volume	10
Emergency key setup	11
Share location	12
Low battery notification	13
Auto answer (Safety)	14
Menu visibility	14
Alarm and Calendar reminders	15
Use camera and view images	15
Complete factory reset	16
Resources	16

Sim insertion

The EasyMate 2 uses a nano sized SIM card to connect to the mobile network. This is the smallest size SIM card and is 8.8 mm X 12.3 mm. Prior to SIM insertion, Olitech strongly advise that users review the SIM insertion instructions in the EasyMate 2 User Manual (pages 11-14) and/or the instructional videos on Olitech's website <https://www.olitech.com.au/easymate2-videos>. Please obtain assistance to insert the SIM if you are not confident with SIM insertion.

Powering on/off

To power the EasyMate 2 on, press and hold the red "end call" key for 5 seconds. The start-up process takes approximately 10-20 seconds. To power the phone off, when on the home screen, press and hold the red "end call" key for 5 seconds.



Lock/unlock keypad

It is recommended to lock the keypad on the EasyMate 2 when the phone is not being actively used. Locking the keypad prevents keys from being accidentally pressed and functions being unintentionally activated.

To lock/unlock the keypad, when on the home screen press and hold the **0** (zero) key for 3 seconds. A message will briefly appear on screen confirming the lock status.



Additional methods of locking the phone can be programmed. These include **Auto keypad lock** and **Lock screen by end-key**. See pages 74-75 in the EasyMate 2 User Manual for additional information.

Note: When the keypad is locked, the following functions can be performed without unlocking the keypad first:

- calls can be answered/rejected;
- the emergency key can be activated;

- 000 or 112 can be dialed; and
- the torch can be activated/deactivated.

Save contacts to Phonebook

1. Press the top right key to select **Phonebook**
2. Press the top left key to select **Options**
3. Scroll to and select **New**
4. Select **Phone** or **SIM** (*storage location*)
5. Edit name and phone number (required); and add photo and/or change ringtone (optional; only present when saving to **Phone**).
6. Select **Save**

Additional information:

- A voice recording can be created and used as a ringtone. This enables the contact's name to be sounded when receiving an incoming call from them (e.g.: "Ryan's calling"). See pages 25-27 of the EasyMate 2 User Manual for additional information.
- When typing the name and phone number, press the **#** key to change the input method (letter settings or numbers). Additional information regarding input methods can be found on page 35 of the EasyMate 2 User Manual.

Photo/speed dial

Eight photo/speed dial phone numbers can be programmed to the number keys 2-9; the number 1 key is reserved for voicemail. These programmed numbers can be dialled via three different methods. The dialling method used depends on what screen is present when the call is initiated:

Dialling method one: When on the home screen, press and hold the allocated number key for 3 seconds to initiate call.

Dialling method two: When **Photo dial** is accessed by pressing the dedicated photo dial key (contacts displayed 4 per page), press the allocated number key (single press) to initiate call.

Dialling method three: If photo dial is accessed by pressing the up navigation key or via the Menu (i.e.: press **Menu** → **Photo dial**) photo dial contacts will be displayed as one contact per page. Use the navigation keys to scroll through contacts. When the contact you want to dial is displayed on screen press the green call key (single press) to initiate call.

Additional information:

- In both the 4 contact per page and single contact per page photo dial screens, use the navigation keys to scroll through contacts.

Photo/speed dial numbers are programmed through the **Photo dial** settings in the main menu. To programme photo dial:

1. When on the home screen, press the **up navigation key**; OR press the top left key to select **Menu**, then scroll to and select **Photo dial**
2. Select **Options**
3. Select **Add from phonebook** to add a saved contact OR **Enter details** to manually enter details (name, phone number, photo and ringtone) and select **Save**

Ringtone

Ringtones and other alert sounds can be changed in the EasyMate 2's **Audio settings**. To change the ringtone:

1. Press the top left key to select **Menu**
2. Scroll to and select **Settings**
3. Scroll to and select **Audio settings**
4. Scroll to and select **Normal**

5. Scroll to and select **Settings**
6. Select **Ring settings**
7. Select **Caller ringtone**
8. Select **Fixed ringtone**
9. Scroll to and select your preferred ringtone

Additional information:

- Audio files (voice recordings or audio files transferred to/recorded on the EasyMate 2) can be used as a ringtone. For further information regarding:
 - transferring audio files from a computer to the EasyMate 2 please refer to pages 47-48 of the EasyMate 2 User Manual;
 - programming an audio file/recording as the ringtone for a specific phonebook contact please refer to pages 25-27 of the EasyMate 2 User Manual.
- To change a message ringtone, select **Message ringtone** at step 7.
- Key tone, low battery alert tone and dial tone can be activated/deactivated by selecting **Other alert rings** at step 6.

Volume key status

To avoid the volume settings being changed

unintentionally, the volume keys can be activated/deactivated in the phone's settings. To change the volume key status:

1. Press the top left key to select **Menu**
2. Scroll to and select **Settings**
3. Scroll to and select **Volume key status**
4. Select **On/Off**

Auto answer when removed from charger

The EasyMate 2 can be programmed to automatically answer an incoming call if it is removed from the charger (either removed from the charging cradle or charging cable removed from the phone) when an incoming call is present. To activate **Auto answer when removed from charger**, when in **Settings**:

1. Scroll to and select **Auto answer when removed from charger**
2. Select **On/Off**

Loudspeaker

The loudspeaker can be activated/deactivated by pressing the direct access loudspeaker key (key above number 1) or the top right key during an active call. Call audio can also be programmed to always divert to loudspeaker. To

do so, when in **Settings**:

1. Scroll to and select **Loudspeaker always on**
2. Select **On**

Note: When this setting is on, audio cannot be transferred back to the earpiece speaker by pressing the Loudspeaker key or the top right key during a call.

Voice guidance

The EasyMate 2 is programmed to speak the function of number and symbol keys, e.g.: “2” and “#” (hash); and main menu headings, e.g.: “phonebook”.

To deactivate/activate this function:

1. Press the top left key to select **Menu**
2. Scroll to and select **Settings**
3. Scroll to and select **Voice guidance**
4. Select either **Key voice output** or **Main menu voice output**
5. Select **Deactivate/Activate**

Amplify receiver volume

The volume of the ear speaker can be boosted an additional 25db by pressing the **Amplify receiver volume** key (key above number 2)

during a call. When pressed during a call, a message will temporarily appear on screen stating **Receiver volume boost activated**. Following the call, a red ear icon will be present along the top of the screen; this ear icon indicates amplify receiver volume is active. **Amplify receiver volume** will remain active for all calls until it is turned off. To turn off this function, during a call press the **Amplify receiver volume** key.

To use this function please ensure the **Amplify receiver volume** key is **On** in Settings (default setting is **On**). To do so, when in **Settings**:

1. Scroll to and select **Amplify receiver volume**
2. Select **On**

Emergency key setup

Information in regards to the functionality of the Emergency key can be found in the EasyMate 2 User Manual (pages 52-56).

To access the Emergency key settings:

1. Press the top left key to select **Menu**
2. Scroll to and select **Safety**
3. Select **Emergency key**

In the Emergency key settings, the following can be programmed:

1. **Status** (turn Emergency key On/Off)
2. **Emergency contacts** (phone numbers to be contacted when the Emergency key is activated; phone numbers that can request the EasyMate 2's location*)
3. Activate/deactivate **Send (text) message**
4. Customise **Emergency (text) message**
5. Activate/deactivate **Warning tone**
6. Turn **Share location** on/off

* Share location must be on in order for emergency contacts to request the EasyMate 2's location. See **Share location** for more details.

Note: all programmed emergency contacts must have the length of their ringtone set to 15 seconds or more to ensure their voicemail cannot answer the emergency call.

Share location

The **Share location** function enables mobile phone numbers programmed in the Emergency contacts list (Emergency key settings) to receive a text message containing a Google Maps link showing the EasyMate 2's location. This location

link should be received within 5 minutes of:

- Activation of the emergency key; and/or
- Sending a text message (at any time) to the EasyMate 2 stating **Location**.

Please consult pages 56-57 of the EasyMate 2 User Manual for more information about the **Share location** function and factors that may impact its functioning.

Low battery notification

The **low battery notification** function allows up to 3 mobile phone numbers to receive a text message stating that the user's phone battery is low. This message is sent when the phones battery drops below 10% capacity.

To set-up the low battery notification function:

1. Press the top left key to select **Menu**
2. Scroll to and select **Safety**
3. Scroll to and select **Low battery notification**
4. Select **Status to On**
5. Select **Notification contacts** and add numbers (up to three mobile numbers)
6. To edit the notification text message, select **Notification SMS**, edit the message and select **Save**.

Auto answer (Safety)

Auto answer enables incoming calls from programmed phone numbers to automatically answer. When the EasyMate 2 automatically answers it diverts audio to loudspeaker.

To set-up the auto answer function:

1. Press the top left key to select **Menu**
2. Scroll to and select **Safety**
3. Scroll to and select **Auto answer**
4. Select **Status to On**
5. Select **Auto answer contacts** and add numbers (up to three phone numbers can be added)

Menu visibility

Menu visibility allows the following menu items to be shown or hidden from the main menu: Phonebook, Message, Call logs, Photo dial, Camera, Organiser, Multimedia and Safety.

Please note, if Message, Photo dial or Phonebook are hidden in Menu visibility, the functions are hidden from the main menu only; their allocated shortcut keys will still function and open the selected function.

To show/hide menu items:

1. Press the top left key to select **Menu**
2. Scroll to and select **Settings**
3. Select **Menu visibility**
4. Select menu items to show/hide

Alarm and Calendar reminders

Alarms and calendar events can be set in the EasyMate 2's **Organiser**. A voice recording can be programmed to sound at the time of an alarm or event, thus creating a voice reminder. See pages 41 - 42 of the EasyMate 2 User Manual for details regarding the programming of alarms and calendar events.

Use camera and view images

To access the camera:

1. Press the top left key to select **Menu**
2. Scroll to and select **Camera**
Camera opens
3. **To take a photo press the magnifier key**
(key above number 2)

When the camera is open, captured images can be viewed by pressing the top left key to select **Options** → select **Image viewer**. For additional information regarding use of the camera, see

page 39 of the EasyMate 2 User Manual.

All images stored on the phone can be viewed in **Menu → Organiser → My files → Phone** or **Menu → Multimedia → Images**. For additional information, see page 33 of the EasyMate 2 User Manual.

Complete factory reset

1. Press the top left key to select **Menu**
2. Scroll to and select **Settings**
3. Select **Phone settings**
4. Scroll to and select **Restore factory settings**
5. Input password **1234**
6. Select **OK**
7. Confirm **OK**

Note: Restoring factory settings will erase all data stored on the phone.

Resources

1. EasyMate 2 User Manual V2
2. Instructional videos
<https://www.olitech.com.au/easymate2-videos>
3. Customer service: support@olitech.com.au
03 9755 8885